

TAG DESCRIPTION TABLE

MIL-PRF-9977K Appendix D

14 September 2004

abbrevtitle

Abbreviated Title

Description: Identifies the abbreviated weapon designation that appears underneath the TO number.

Source paragraph: MIL-PRF-9977K 3.3.3.1.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

abbrsect

Abbreviation Section

Description: Identifies the paragraph used to define abbreviations/acronyms and the associated list.

Source paragraph: 4.3.4 & 4.5.9

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1* | ldstep1*),
subpara1*), (abbrtitle?, acronymlist)

foreword

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item

applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

abbrtitle

Abbreviation Title

Description: Identifies the title for the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

abbrsect

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

accprep

Installed Accessory Preparation

Description: Found in section V of Chapter 1. Primary paragraph that contains all necessary steps to prepare each installed weapon (munition) accessory for functional/stray voltage checks and weapons (munitions) loading.

Source paragraph: 3.3.2.7.2 (9977K)

Content Model: (para0+ | natitle)

airprep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)		Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

acftprep

Aircraft Preparation

Description: Found in section V of Chapter 1. Primary paragraph that contains all necessary steps to prepare each installed weapon (munition) accessory for functional/stray voltage checks and weapons (munitions) loading.

Source paragraph: 3.3.2.7.1 (9977K)

Content Model: (para0+ | natitle)

airprep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

acronym

Acronym/Abbreviation Definition

Description: Identifies the first time an acronym or abbreviation is used in a chapter. The "def" part of the acronym is used to define the acronym/abbreviation, while the "term" part of the acronym contains the actual acronym/abbreviation. Within the text, the "term" portion will be surrounded with parenthesis.

Source paragraph: 4.3.4 & 4.5.9

Content Model: (def, term)

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

acronymlist

Acronym/Abbreviation List

Description: Identifies the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: (term, def) *

abbrsect

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.5IN	Allows you to set the right term width.
ltermwidth	NUTOKEN	1IN	Allows you to set the left term width.
autobuild	CDATA	#CONREF	Allows you to automatically build this list.

airdesc

Appendix

Description: Section III of Chapter 1. Contains the aircraft description and general arrangement in an illustrated and informational form.

Source paragraph: 3.3.2.3 (9977K)

Content Model: (para0+ | natitle)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

airprep

Aircraft Preparation

Description: Container element. Section V of Chapter 1. Contains detailed steps required to prepare the basic aircraft and installed weapon (munition) accessories for functional/stray voltage checks and weapons (munitions) loading.

Source paragraph: 3.3.2.7 (9977K)

Content Model: ((para0+ | natitle)?, acftprep, accprep)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.

id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

airprepld

Aircraft Preparation

Description: Subordinate paragraph in Servicing/Loading Procedures of Chapter 2.

Source paragraph: 3.7.2.2.3 (9977K)

Content Model: ((title?, warning*, caution*, note*, (para, note*), (step1* | ldstep1*), subpara1*))

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

appendix

Appendix

Description: Identifies an appendix to the manual.

Source paragraph: 4.2.9.6

Content Model: (title, para0+)

rear

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.

delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

applic

Applicability/Effectivity Definition Entry

Description: Defines applicability/effectivity markings.

Source paragraph: 4.3f & 4.5.9

Content Model: (term, def)

applicdef

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	REQUIRED	Allows the author to identify each element and later reference it by the id value.

applicabil

Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicabilty/effectivity markings defined in the applicability definition (applicdef) to appear at that point in running text.

Source paragraph: 4.3f

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
security	U C S N	N	Allows security classification of section.

applicdef

Applicability/Effectivity Definition

Description: Identifies the paragraph used to define applicability/effectivity markings, and the associated list.

Source paragraph: 4.3f

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1* | ldstep1*), subpara1*), (applttitle?, applichd?, applic+))

foreword

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	NOTOKEN	2.5IN	Allows you to set the right term width.
ltermwidth	NOTOKEN	1IN	Allows you to set the left term width.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcf	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hcfi	NUMBER	0	Hardness Critical Item
ocf	NUMBER	0	Observable Critical Process
ocfi	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type

inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

applichd

Applicabilty/Effectivity List Column Headings

Description: Defines the column headings used for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: (term, def)

applicdef

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

appltile

Applicability/Effectivity Definition

Description: Identifies the title for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

applicdef

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

authnot

Authority Notice

Description: Identifies the authority notice at the bottom of the title page.

Source paragraph: 4.5.1.15
Content Model: #PCDATA
idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

body

Body

Description: Identifies the portion of the manual where chapters and sections are used, exclusive of front matter and appendices, indexes, etc.

Source paragraph: 4.2.9.3 & 4.5.1.3.2 & 3.2.38

Content Model: (suppinfo, munitldproc)

docnnmunld

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numcols	(1 2)	#REQUIRED	Set body to either one column or two columns.

brk

Break

Description: This element is used to indicate that a column, line, or page break should be forced at that point. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: EMPTY

docnnmunld

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	(COL LINE LINE NPG)		Allows you to define where you want the break to occur.

cartins

Cartridge Installation

Description: Subordinate paragraph in Loading Procedures of Chapter 2. Used in combination with Loading either as cartridge installation/loading and/or loading/cartridge installation.

Source paragraph: 3.3.3.3.3 and 3.3.3.3.5 (9977K)

Content Model: ((%titles)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*))

munitldproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

caution

Caution

Description: Identifies a CAUTION in the manual.

Source paragraph: 4.3.10

Content Model: (para*)

%parazero, %nparcon, %fpi, %wcn, %entry, safesum

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type

inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

change

Changed Information

Description: Identifies material that has been changed. In order to add material, the "type" attribute should be set to "add", and the "change" element should surround the added material. In order to delete material where a complete history of all changes to the document are being preserved, the "type" attribute should be set to "delete" and the "change" element should surround the deleted material. If all changes are not being preserved, change the material and surround it with a "change" element, setting the "type" attribute to "add".

Source paragraph: 4.7.3.9

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
level	NMTOKEN	#REQUIRED	Description not available.
change	(ADD DELETE)	ADD	Allows you to add or delete a change.
mark	NUMBER	1	Allows you the option to mark your changes.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

chgdate

Change Date

Description: Identifies the date of the latest change.

Source paragraph: 4.5.1.17

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

NONE

chghistory

Change History

Description: Identifies the beginning of the change history dates. The first date in the chghistory is the original date and subsequent dates are change 1, change 2, etc.

Source paragraph: 4.5.3

Content Model: (chginfo*)

lep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chginfo

Change Information

Description: Container element to identify the change information contained in the change history of the document.

Source paragraph: 4.5.3

Content Model: (chgtxt?, date)

lep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chginsst

Change Instruction Sheet

Description: Identifies the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: (chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

NONE

chglist

Change List

Description: Identifies the Remove Pages and Insert Pages columns on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: (tabmat | (removepg, insertpg)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chgnum

Change Number/Letter

Description: Identifies the latest change number/letter.

Source paragraph: 4.7.3.1, 4.2.1.4.2.3, 4.5.1.17, & 4.5.3.1

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chgpara

Change para

Description: Identifies the paragraph change status.

Source paragraph: 4.7.3.11.2

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chgrec

Change Record

Description: Identifies the change record page. This page will be an empty table whose contents will be completed by the person filing the change pages in the manual. The change record page will be automatically generated by the FOSI.

Source paragraph: 4.5.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

chgtxt

Change Text

Description: Provides an alphabetical representation of the current change level.

Source paragraph: 4.5.3

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

clink

Contextual Link

Description: One of several HyTime elements. Can be used in any situation similar to the xref or extref element - will reference any nameloc declared.

Source paragraph:

Content Model: (PCDATA) *

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
linkend	CDATA	#IMPLIED	References a linkend declared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implemented.

HyBase	NAME #FIXED	HYLINK	Used in combination with HyTime to establish contextual link.
HyBnames	CDATA #FIXED	REFSUB LINKEND	Used in combination with HyTime to establish contextual link.
anchrole	CDATA #FIXED	REFMARK REF- SUB #LIST	Used in combination with HyTime to establish an anchor role for contextual links.
anchcstr	NAMES	SELF REQUIRED	Used in combination with HyTime to establish type of anchor string defined for a contextual link.

cogact

Cognizant Field Activity

Description: Identifies Cognizant Field Activity on the title page and is included in the distribution statement. This is a Navy requirement.

Source paragraph: 4.5.1.11

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

colspec

Column Specification

Description: Defines a column in a table. Each column must have a column specification. The column specification defines the width of the column and an optional name used when column is starting or ending a horizontal span or referenced in a table entry. Column specifications in a table group apply to the table heading (boxheads) and the table body. The table heading can redefine the column specifications if needed, however, the table body must use the column specifications defined in the table group.

Source paragraph: 4.3.9

Content Model: EMPTY

tgroup, thead

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows you to assign a name to a column.
colnum	NUMBER	#IMPLIED	Allows you to assign a number to a column.

align	(LEFT RIGHT CENTER JUSTIFY CHAR)	#IMPLIED	Allows you to align entered text.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Alignment Character
leftmar	NUTOKEN	#IMPLIED	Allows you to define a left margin if desired.
rightmar	NUTOKEN	#IMPLIED	Allows you to define a right margin if desired.
topmar	NUTOKEN	#IMPLIED	Allows you to define a top margin if desired.
botmar	NUTOKEN	#IMPLIED	Allows you to define a bottom margin if desired.
mindepth	NUTOKEN	#IMPLIED	Allows you to define a minimum depth if desired.
colwidth	CDATA	#IMPLIED	Allows you to define the column widths.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to seperate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to seperate rows.

contents

Table of Contents

Description: Identifies the table of contents. For Army documents, the table of contents consists of chapter and section titles. For all other services, the table of contents consists of chapter, section, and paragraph titles. If an index is used, the table of contents consists of chapter, section, and primary paragraph titles. This information is automatically compiled by the FOSI.

Source paragraph: 4.5.6

Content Model: #PCDATA

front

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Allows the contents to be automatically generated. Set autobuild="1".
security	U C S N	N	Allows security classification of section.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.

contractno

Contract Number

Description: Identifies the contract number on the title page.

Source paragraph: 4.5.1.4
Content Model: #PCDATA
idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

copyright

Copyright Notice

Description: Identifies the copyright notice on the title page.
Source paragraph: 4.1.2 & 4.5.1.14
Content Model: #PCDATA
idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

dataiden

Data Identification

Description: May be used to identify specific types of data (e.g., hazardous materials, special tools, etc.). Use of this element does not affect the formatted output, but is intended to be used in database functions and data searches.
Source paragraph: 4.5.1.7, 4.5.1.16, 4.5.1.17, & 4.5.3.1
Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+
%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	CDATA	#REQUIRED	
security	U C S N	N	Allows security classification of section.

date

Date

Description: Identifies a date.

Source paragraph: 4.5.1.17 & 4.5.9.4b

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ratdentry, tctorow

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

dateinc

Date Incorporated

Description: Identifies the date the information affected by the directive or engineering change proposal was incorporated into the manual.

Source paragraph: 4.5.9.4d

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ratdentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

def

Definition

Description: Identifies a term and definition in a list.

Source paragraph: 4.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

acronym, acronymlist, applic, applichd, defhd, deflist, symsect

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

defhd

Definition List Column Headings

Description: Identifies the column headings for a definition list.

Source paragraph: 4.3.4

Content Model: (term, def)

deflist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

deflist

Definition List

Description: Identifies a two-column definition list. This element can be used when a listing is needed to define particular terms.

Source paragraph: 4.3.4

Content Model: (title?, defhd?, (term, def)+)

glossary, %paracon

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	1.9IN	Allows you to set the right term width.
ltermwidth	NUTOKEN	0.7IN	Allows you to set the left term width.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

destr

Destruction Notice

Description: Identifies the destruction notice on the title page.

Source paragraph: 4.5.1.13

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

discl

Disclosure Notice

Description: Identifies the disclosure notice on the title page. The title is automatically generated by the FOSI.

Source paragraph: 4.5.1.10

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
disclos1	CDATA	#IMPLIED	Description not available.

distrib

Distribution Statement

Description: Identifies the distribution statement. The title is automatically generated by the FOSI.

Source paragraph: 4.5.1.11

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	(A B C D E F X)	#IMPLIED	Displays what type of distribution code is used for the manual.

delayflt

Delayed Flight or Alert

Description: Subordinate paragraph in Loading Procedures of Chapter 2. Contains procedural information for safing of aircraft accessories, weapons (munitions), and impulse cartridges.

Source paragraph: 3.3.3.3.7 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*))

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

doc

Document

Description: Identifies the entire document (technical manual).

Source paragraph: 4.1.7

Content Model: (docicturn)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD)	#REQUIRED	Identifies which branch of service.
docid	CDATA	#IMPLIED	Allows for the author to define an identification number for the document.
docstat	(REVISION CHANGE PRELIM DRAFT FORMAL)	PRELIM	Author can stipulate what form the manual is in.
verstatpg	(VER UN-VER)	VER	Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail.
Index	NUMBER	0	Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC
security	(U C S N)	N	Identifies security level of the document
controlno	CDATA	00000000	System generated attribute values used included for compliance with the JCALS menu structure.
cycle	CDATA	NEW	System generated attribute values used included for compliance with the JCALS menu structure.
chglevel	NUMBER	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
initlabel	NUMBER	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
initpage	NUMBER	1.	System generated attribute values used included for compliance with the JCALS menu structure.
docno	CDATA	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
highguid	NUMBER	0	System generated attribute values used included for compliance with the JCALS menu structure.
labelstyle	CDATA	FAN	System generated attribute values used included for compliance with the JCALS menu structure.
HyTime	NAME #FIXED	HYDOC	Used to alert the processing system that this is a HyTime compliant document. This attribute is only required and/or effective with a HyTime aware processor.

docnmmunld

Nonnuclear Munitions Loading Procedures Document

Description: Identifies the entire document (Technical Manual)

Source paragraph: 3.6 (9977K)

Content Model: (front, body, rear?)

NA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

docpart

(Document) Part

Description: Identifies the next breakdown of a volume.

Source paragraph: 4.5.1

Content Model: ((front | auxfront), body, rear?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
delttype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Used during the change package process to indicate the current status of the element.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
security	(U C S N) N		Identifies security level of the document

docpartn

(Document) Part Number

Description: Specifies the number used to identify a (document) part

Source paragraph: NONE

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

doctype

Type of Manual

Description: Identifies the type of manual on the title page (e.g., maintenance instructions, illustrated parts breakdown, inspection manual, etc.).

Source paragraph: 4.1.7

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

downgrd

Downgrade Notice

Description: Identifies the classification downgrade notice on the title page.

Source paragraph: 4.4

Content Model: (phrase | oadr)

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

ecpno

Engineering Change Proposal Number

Description: Identifies the ECP Number in the record of applicable technical directives.

Source paragraph: 4.5.9.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ATTRIBUTE LIST*Only these attributes are applicable and supported by the fosi.*

Attribute	Type	Default	Description
NONE			

effdatenot

Effective Date Notice

Description: Identifies the effective date notice on the title page.*Source paragraph:* 4.5.1.8*Content Model:* #PCDATA

idinfo

ATTRIBUTE LIST*Only these attributes are applicable and supported by the fosi.*

Attribute	Type	Default	Description
NONE			

emergproc

Emergency Procedures

Description: Identifies the emergency procedures data contained in Chapter 1.*Source paragraph:* 3.7.2.1.3 (9977K)*Content Model:* ((title, warning*, caution*, note*, (para, note?)?, (step1* | ldstep1*) | natitle))

suppinfo

ATTRIBUTE LIST*Only these attributes are applicable and supported by the fosi.*

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.

delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

emphasis

Emphasis

Description: Identifies portions of text to be highlighted (e.g., underline, bold, etc.). This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

%text, expcont

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	(U B BU BI Q X O SUP SUB UI)	#REQUIRED	Displays different types of emphasis. u=underline b=bold bu=bold/underline i=italics bi=bold/italics q=quotes x=box o=strike out sup=superscript sub=subscript ui=underline/italics
fontsize	NUTOKEN	#IMPLIED	Description not available.
color	(BLACK WHITE RED ORANGE YELLOW GREEN BLUE VI- OLET BROWN GRAY)	#IMPLIED	Option to choose color.

entry

Table Entry

Description: Identifies a table entry (cell).

Source paragraph: 4.2.7

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex)+ | (randlist | deflist | seqlist) | warning |
caution | note)+

row

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows you to identify an name for each column.
spanname	NMTOKEN	#IMPLIED	Allows you to identify a span name for any columns spanned.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
morerows	NUMBER	0	This allows you to add more rows.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to seperate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to seperate rows.
rotate	NUMBER	0	Allows you to rotate text in a column.
valign	(TOP MID-DLE BOT-TOM)	#IMPLIED	Allows you to vertically align text within a row.
align	(LEFT RIGHT CENTER JUSTIFY CHAR)	#IMPLIED	Allows you to align text within a column.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Alignment Character
security	U C S N	N	Allows security classification of section.

entrytbl

Entry Table

Description: Identifies a table within a table entry. This element allows a table cell to be divided into a sub-table, with its own set of rows, columns, and entries. Use of this element basically allows the author to create a table within a table.

Source paragraph: 4.2.7

Content Model: (colspec*, spanspec*, thead?, tbody)

row

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Allows you to identify how many columns.
colname	NMTOKEN	#IMPLIED	Allows you to identify an name for each column.

spanname	NMTOKEN	#IMPLIED	Allows you to identify a span name for any columns spanned.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows.
align	(LEFT RIGHT CENTER JUSTIFY CHAR)	#IMPLIED	Allows you to align text within a column.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Alignment Character
security	U C S N	N	Allows security classification of section.

esds

Electrostatic Discharge Sensitive Symbol

Description: Identifies the ESDS symbol. Use of this element will cause the ESDS symbol to appear at that point in the running text. The "esds" attribute should be used to place the ESDS symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.4

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

expcont

Export Control Notice

Description: Identifies the export control notice on the title page. Note that the export control notice entity (&expcontnot;) may be used in place of entering the text manually.

Source paragraph: 4.5.1.12

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

extref

External Reference

Description: Identifies a cross-reference to another document. Use of this element is optional in that the referenced document number may be entered without using this element.

Source paragraph: 4.3.1m

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
externalid	CDATA	#IMPLIED	Allows you to specify the ID of an external document that can be referenced.
HyTime	NAME #FIXED	CLINK	Used in combination with HyTime to establish contextual link.
HyNames	CDATA #FIXED	LINKEND XREFID	Used in combination with HyTime to establish contextual link.

fcp

Fracture Critical Process

Description: Identifies fatigue and fracture critical parts.

Source paragraph: 4.3.8.5

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

fctfuncchk

Flight Circuit Test/Functional Checks

Description: Section VI of Chapter 1. Contains all necessary steps to perform functional checks of the weapons (munitions) control/release/fire and jettison systems.

Source paragraph: 3.3.2.8 (9977K)

Content Model: (para0+ | natitle)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

figno

Figure Number

Description: Identifies the figure number within the illustration list when the illustration list is manually tagged.

Source paragraph: NONE

Content Model: #PCDATA

illuslist, volilluslist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

figtable

Table within a figure

Description: Identifies a table contained within a figure, which does not have a table number or name, and does not appear in the list of tables. An example would be a component table on a schematic diagram.

Source paragraph: 4.3.9.1

Content Model: (tgroup)

%fig, subfig

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
frame	(TOP BOT-TOM TOPBOT ALL SIDES NONE)	ALL	Allows you to choose what type of table frame you need.
colsep	NUMBER	1	Allows you to include a vertical line to separate columns.
rowsep	NUMBER	0	Allows you to include a horizontal line to separate rows.
tbwidth	NUTOKEN	#IMPLIED	Allows you to determine the table width.
tbdepth	NUTOKEN	#IMPLIED	Allows you to determine the table depth.
horrefpt	(LEFT RIGHT)	LEFT	Horizontal reference point.
verrefp	(VTOP VBOTTOM)	VTOP	Vertical reference point.
coordst	CDATA	0,10000	Coordinate start
assocfig	IDREF	#IMPLIED	Associate figure
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

figure

Figure

Description: Identifies an illustration.

Source paragraph: 4.2.8

Content Model: (((title, ((subfig, subfig+) | (graphic | figtable)+))

suppinfo, munitldproc, %inclus, foreword, safesum

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pgwide	NUMBER	1	Specifies if the graphic fills the page or column. Set it equal to "0", it will fit in column.
orient	"PORT LAND"	PORT	Allows author to specify the orientation of the graphic and/or table. Options are portrait and landscape.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

foldout

Foldout

Description: Identifies a foldout.

Source paragraph: 4.2.4.1

Content Model: (((title, ((subfig, subfig+) | (graphic | figtable)+))

foldsect

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

pgstyle	(11X17 11X20.5 11X24 11X27.5 11X31 11X34.5 11X38 11X41.5 11X45)	#IMPLIED	Identifies available foldout pageset options.
blankapron	NUMBER	1	Toggle on whether you want a blankapron or not.
pgwide	NUMBER	1	Specifies if the graphic fills the page or column. Set it equal to "0", it will fit in column.
orient	"PORT LAND"	PORT	Allows author to specify the orientation of the graphic and/or table. Options are portrait and landscape.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

foldsect

Foldout Section

Description: Identifies the area where foldouts are placed when they are included at the end of the manual. This element is not marked as a chapter or section, but is merely a placeholder for the foldouts.

Source paragraph: 4.2.4.1d

Content Model: (foldout+)

rear

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

foreword

Foreword

Description: Identifies the foreword of the manual. This element is identical to the "preface" and "introduction" elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc)*, tmimprep?

front

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.

front

Front Matter

Description: Identifies the front matter of the manual.

Source paragraph: 4.5

Content Model: (idinfo, lep, verstat?, contents, foreword, safesum?)

docnnmunld

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
t2page	NUMBER	0	A toggle that allows the author to turn the second title page on if necessary.
numcols	(1 2)	#REQUIRED	Set body to either one column or two columns.

ftnote

Footnote

Description: Identifies footnotes to paragraphs and tables. The footnote appears on the same page that the corresponding footnote reference (<ftnref>) occurs. Only the footnote whose "id" matches the "xrefid" specified in the footnote reference will appear. Footnotes to text will be displayed at the bottom of the page where the footnote is referenced.

Source paragraph: 4.3.1n, 4.2.2

Content Model: (((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+) | (randlist | deflist | seqlist))+
appendix, body, front

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
security	U C S N	N	Allows security classification of section.

ftnref

Footnote Reference

Description: Identifies a reference to a footnote. This element will cause the footnote number/letter/symbol to appear at the point in the text where used, and will cause the footnote number/letter/symbol and the footnote text to appear at the bottom of the page.

Source paragraph: 4.3.1n

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Allows the user to set up an external reference.
mark	(NUM SYM NUM ALPHA)		Number, symbol, alpha number to mark footnote.

fuzerem

Fuze Removal

Description: Provides necessary steps to safe and remove fuzes from nunnuclear munitions.

Source paragraph: 3.6.3.4.4 (9977K)

Content Model: (%nparcon; , subpara1*)

munitunloadproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

general

General

Description: The firstb section of Chapter 2 and subsequent chapters. Contains the following subordinate paragraphs: scope, support equipment, and specific safety requirements.

Source paragraph: 3.3.3.2 (9977K)

Content Model: ((%title;, warning*, caution*, note*, (para, note?)?, (step1* | ldstep1*), scope, suppequipdesc, specsafreq) | (natitle))

munitldproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

genproc

General Procedure

Description: Section IV of chapter 1. Contains general information and/or detailed procedures for selected items of a repetitive nature.

Source paragraph: 3.3.2.6 (9977K)

Content Model: (para0+ | natitle)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.

security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

gensafreq

General Safety Requirements

Description: Section 1 of Chapter 1. Contains safety procedures related to aircraft servicing, munitions loaded aircraft, munitions loading/unloading, and munitions.

Source paragraph: 3.7.2.1.2 (9977K)

Content Model: ((title, warning*, caution*, note*, (para, note?)?, (step1* | ldstep1*) | (natitle))

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type

inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

glossary

Glossary

Description: Identifies the glossary of the manual.

Source paragraph: 4.2.9.7

Content Model: (deflist)

rear

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

glosslist

Glossary List

Description: Container element for the glossary list of definitions and terms.

Source paragraph: NONE

Content Model: (letter?, (term, def))+

glossary

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

graphic

Graphic

Description: Identifies a graphic within a figure, or a graphic within running text or tables. If used within running text, no figure number or title will be generated. Note that the HCP and ESDS symbols can be placed in running text by using the "hcp" and "esds" elements. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: EMPTY

warndef, cautdef, %text, %fig, subfig, %icon

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
boardno	ENTITY	#REQUIRED	Allows the author to place the graphic name here.
graphsty	NMTOKEN	#IMPLIED	Graphic style
llcordra	CDATA	#IMPLIED	Lower left world coordinates (1,1). If scalefit="0" and reprowid is not specified default is lower left.
rucordra	CDATA	#IMPLIED	Upper right world coordinates (10000,10000). If scalefit="0" and reprodep is not specified default is upper right.
reprowid	NUTOKEN	#IMPLIED	Specifies the horizontal dimension of a graphic bounding box (width).
reprodep	NUTOKEN	#IMPLIED	Specifies the vertical dimension of a graphic bounding box (depth).
hscale	NUMBER	#IMPLIED	Horizontal Scaling
vscale	NUMBER	#IMPLIED	Vertical Scaling
scalefit	NUMBER	#IMPLIED	Scale to fit. No affect if hscale and vscale set to zero.
hplace	LEFT RIGHT CENTER	#IMPLIED	Description not available.
vplace	TOP MIDDLE BOTTOM	#IMPLIED	Description not available.
coordst	CDATA	#IMPLIED	Coordinate start
coordend	CDATA	#IMPLIED	Description not available.
color	(BLACK WHITE RED ORANGE YELLOW GREEN BLUE VIOLET BROWN GRAY)	#IMPLIED	Option to choose color.

icon	YES NO	NO	Description not available.
security	U C S N	N	Allows security classification of section.

hazmat

Hazardous Material Name

Description: Identifies the hazardous material name used with a hazardous material warning icon.

Source paragraph: 4.3.10.1

Content Model: #PCDATA

icon

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

hci

Hardness Critical Item

Description: Identifies the HCI symbol. Use of this element will cause the HCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCI symbol in a paragraph. The "hci" attribute should be used to place the HCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.3.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

hcp

Hardness Critical Process Symbol

Description: Identifies the HCP symbol. Use of this element will cause the HCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCP symbol in a paragraph. The "hcp" attribute should be used to place the HCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.3.1

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

icon

Hazardous Material Warning Icon

Description: Identifies the hazardous material warnings. The hazardous material warning consists of a graphic(s) (e.g., fire icon, poison icon, etc.), the hazardous material name, and the sequence number which identifies the order in which the hazardous material warnings are included in the safety summary. See Appendix A for further information on hazardous material warnings.

Source paragraph: 4.3.10.1

Content Model: (graphic+, hazmat, seqno)

warning

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.

idinfo

Identification Information (Title Page)

Description: Identifies the title page and cover (if used) of the manual.

Source paragraph: 4.5.1

Content Model: (tmidno+, pretmidno*, volnum?, revnum?, doctype, maintlvl?, prtitle, subtitle?, (mfr+, contractno+)?, seal?, superseded?, suppl*, effdatenot?, volnot?, discl?, distrib, expcont?, destr?, copyright*, cogact?, authnot, downgrd?, pubdate, (chgunum, chgdate)?)

front

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
tmidnolen	NUTOKEN	10EM	Description not available.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED "UNVERIFIED" VERIFIED)		Identifies verification status.

ilink

Independet Link

Description: One of several HyTime elements. Used in a situation of indirection where a specific ID is not declared in an external document and must be declared using nameloc and nmlist elements.

Source paragraph:

Content Model: (PCDATA) *

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
linkends	CDATA	#IMPLIED	References the linkends delcared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and im-plement.
anchrole	CDATA	#REQUIRED	Defines the anchor role assumed by the independent link. Used in combination with HyTime.

index

Index

Description: Identifies the index.

Source paragraph: 4.2.9.8

Content Model: (letter?, (preentry, secentry*)) *

rear

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Allows you to automatically build this list.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
security	U C S N	N	Allows security classification of section.

insertpg

Insert Page Column Entry

Description: Identifies an entry within the Insert Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

internatlst

International Standardization Agreement Note

Description: Identifies the international standardization agreement note. The paragraph number and title, of this note will be automatically generated by the FOSI.

Source paragraph: 4.5.9.1

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

foreword

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)		Identifies verification status.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

item

Item

Description: Identifies an item within a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

randlist, seqlist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
security	U C S N	N	Allows security classification of section.

ldstep1

First Level Loading Procedural Step

Description: Identifies a first level procedural step.

Source paragraph:

Content Model: warning*, caution?, note?, para, note?, ldstep2*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
delttype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level

delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

ldstep2

Second Level Loading Procedural Step

Description: Identifies a second level procedural step.

Source paragraph:

Content Model: warning*, caution?, note?, para, note?, ldstep3*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
deltype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

Idstep4

Fourth Level Loading Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph:

Content Model: warning*, caution?, note?, para, note?

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
delttype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

legend

Legend

Description: A tabular listing of the index numbers/letters and their meanings.

Source paragraph: 4.6.17

Content Model: (tabmat)

subfig

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

lep

List of Effective Pages (LEP)

Description: Identifies the list of effective pages for the manual.

Source paragraph: 4.5.3

Content Model: (chghist*, lepcontents)

front

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.

lepchg

LEP Change

Description:

Source paragraph: 4.5.3.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

lepcontents

LEP Contents

Description: Contains the entries for the lep. The FOSI can automatically generate this.

Source paragraph: 4.5.3

Content Model: (lepentry+)

lep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Allows the contents to be automatically generated. Set autobuild="1".

lepentry

LEP Entry

Description: Contains the entries for the lep. The FOSI can automatically generate this.

Source paragraph: 4.5.3

Content Model: (leppage, lepchg)

lepcontents

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

lepchg

LEP Change

Description: Contains the change number for each page listed in the lep. The FOSI can automatically generate this.

Source paragraph: 4.5.3.1

Content Model: #PCDATA

lepentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

leppage

LEP Page

Description: Contains the page number for each listing in the lep. The FOSI can automatically generate this.

Source paragraph: 4.5.3

Content Model: #PCDATA

lepentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

letter

Letter

Description: Letter heading for the index.

Source paragraph: 4.2.9.8

Content Model: #PCDATA

index

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

line

Line

Description: This element is used to indicate that a column or line should be forced at that point.

Source paragraph: N/A

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
prespace	CDATA	#IMPLIED	Allows the author to set amount of space before/above the line used.
postspace	CDATA	#IMPLIED	Allows the author to set amount of space after/below the line used.
quad	(LEFT CENTER RIGHT JUSTIFY)	LEFT	Allows the author to horizontally adjust this text.
indent	CDATA	#IMPLIED	Allows the author to indent this text.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

load

Loading

Description: Primary paragraph under munitions loading procedures of Chapter 2. Contains steps required to load weapons.

Source paragraph: 3.3.3.3 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*))

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.

deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

loadprep

Weapons (munitions) Preparation

Description: Subordinate paragraph under munitions loading procedures of Chapter 2. Applicable to a single weapon (munition), multiple rack, and preloaded accessories. Includes steps required to inspect and prepare each weapon (munition), including components.

Source paragraph: 3.3.3.3.2 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subparal*))

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

location

Location (Not Used; Under Review)

Description: Identifies the placement of a floating object such as a figure, table or figure table. This element is globally included on the document element.

Source paragraph: N/A

Content Model: EMPTY

d o c n n m u n l d

lrp

List of Related Publications

Description: Identifies the paragraph used to list related publications and the associated list.

Source paragraph: 4.5.9.2

Content Model: ((title,warning*,caution?,note?,(para,note?)?,(step1* | ldstep1*), sub-para1*), lrptable?))

foreword

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
ltermwidth	NUTOKEN	1.63IN	Allows you to set the left term width.
rtermwidth	NUTOKEN	1.9IN	Allows you to set the right term width.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED "UNVERIFIED" VERIFIED)		Identifies verification status.

label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

Irpretry

List of Related Publications Entry

Description: Identifies an entry in the list of related publications. When the value of the id attribute is specified via the xrefid attribute of the extref element, the title of the publication appears.

Source paragraph: 4.5.9.2

Content Model: ((partno | modelno | typedes))* , tmidno, title)

lrptable

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#REQUIRED	This allows you to identify each element and later reference it by its id value.

Irptable

List of Related Publications Table

Description: Listing of publications referenced in the TM.

Source paragraph: 4.5.9.2

Content Model: (lrpretry+)

%lrp

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

maintlvl

Maintenance Level

Description: Identifies the maintenance level of the manual (e.g., organizational, intermediate, depot, etc.) on the title page.

Source paragraph: 4.5.1.3.3

Content Model: #PCDATA

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

mfr

Manufacturer

Description: Identifies the manufacturer of the equipment on the title page.

Source paragraph: 4.5.1.3.6

Content Model: #PCDATA
idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

modelno

Model Number

Description: Identifies the model number of the equipment on the title page.

Source paragraph: 4.5.1.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

lrpentry, prttitle

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

modreq

Modification Request (Not Used; Under Review)

Description: The modification request element identifies a marking which document editors may place into the document instance to indicate where modification should be made. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrinfo?, mrmod, mrrespns?)

d o c n n m u n l d

mrchgtxt

Modification Request Change Text (Not Used; Under Review)

Description: Identifies the modification request change text used to indicate editorial changes during document production. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: ANY

m r m o d

mrngenmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

m r m o d

mrinfo

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: ANY

m o d r e q

mrinstr

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

m r m o d

mritem

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: #PCDATA

m r l i s t

mrlist

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mritem+)

mrreason, mrrespns, mrngenmod, mrinstr

mrmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrreason?, (mrngenmod | (mrinstr?, mrchgtxt)))

m o d r e q

mrpara

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: #PCDATA

mrreason, mrrespns, mrngenmod, mrinstr

mrreason

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

m r m o d

mrrespns

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)*

munitldproc

Munitions Loading Procedures

Description: Identifies Chapter 2 and subsequent chapters of the manual, containing Sections I through III (general, rackload, munitunloadproc). One chapter shall be used for each munition or group of munitions. Includes weapons (munitions) general information, loading, and unloading on the aircraft.

Source paragraph: 3.6c (9977K)

Content Model: (%titles;, general, rackload, munitunloadproc) +(figure | table | foldout)
body

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

munitunloadproc

Munitions Unloading Procedures

Description: Section III of Chapter 2 . Includes weapons (munitions) safing, preloading, unloading, and either fuze removal or sensor removal from the weapon (munition).

Source paragraph: 3.6.3.4 (9977K)

Content Model: (%parazero;, safing, preunload, unload+, (fuzerem | sensorrem))

munitldproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referncing objects that do not have the traditional SGML id.

Source paragraph:

Content Model: (nmlist)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
HyBase	NAME #FIXED	NAMELOC	Assigns nameloc as the HyBase attribute.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.

natitle

Not Applicable Title

Description: Used when specific paragraph title is not applicable.

Source paragraph: 3.7.2

Content Model: %text;

emergproc, gensafreq

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

nmlist

Name List - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a description of the location of the entity or element reference in the nameloc element. Useful for referncing objects that do not have the traditional SGML id and/or entities that reside in external documents.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
nametype	(ENTITY ELEMENT)	ENTITY	Identifies whether the external reference is an element or entity.
docorsub	ENTITY	#IMPLIED	Defines the entity name of the external document as declared in the entity declarations at the top of the tagged instance. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
HyBase	NAME #FIXED	NMSPLOC	Used in conjunction with HyTime to set up independent and contextual links.
impsrc	NAME #FIXED	GROVERT	Used in conjunction with HyTime to set up independent and contextual links.
HyBnames	CDATA #FIXED	LOCSRC DOCOR-SUBNAMESPC NAMETYPE #MAPTOKEN ELEMENTS ELEMENT #MAPTOKEN ENTITIES ENTITY	Used in conjunction with HyTime to set up independent and contextual links.
notspace	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.

notname	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
notprop	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
direct	(DIRECT IN-DIRECT)	INDIRECT	Used in conjunction with HyTime to set up independent and contextual links.
locsrc	CDATA	#IMPLIED	Used in conjunction with HyTime to set up independent and contextual links.
cantcnst	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.

nomen

Nomenclature

Description: Identifies the nomenclature of the equipment on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

note

Note

Description: Identifies a NOTE in the manual.

Source paragraph: 4.3.10

Content Model: (para*)

%parazero, %nparcon, %fpi, %wcn, %stepcon, %nparcon1, %entry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

nsn

National Stock Number

Description: Identifies the national stock number of the equipment on the title page.

Source paragraph: 4.5.1.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

nsp

Nuclear Surety Procedure Symbol

Description: Identifies the nsp symbol. Use of this element will cause the nsp symbol to appear at that point in the running text. The "nsp" attribute should be used to place the nsp symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.2.1

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

oadr

Official Authority Downgrade Review Notice

Description: Identifies the official authority downgrade review notice on the title page. This notice is used only on classified manuals.

Source paragraph: 4.4 & 4.5.1.10

Content Model: #PCDATA
idinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

object

Multimedia Object

Description: Developed for use in interactive manuals to evoke multimedia applications.

Source paragraph:

Content Model: (param) *

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
objectno	ENTITY	#REQUIRED	References the object number of the application being referenced.
reprowid	NUTOKEN	#IMPLIED	Provides width of object being invoked, especially if graphic or foldout from external document.
reprodep	NUTOKEN	#IMPLIED	Provides depth of object being invoked, especially if graphic or foldout from external document.
type	CDATA	#IMPLIED	Provides details about the type of applications being referenced.
security	(U C S N)	N	Identifies security level of the document

objmedia

Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph:

Content Model: (title, ((subobjmed, subobjmed+) | object)) - (figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.

nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.. All paragraphs which address fracture critical processes shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(U C S N) N		Identifies security level of the document

oci

Observable Critical Item

Description: Identifies the OCI symbol. Use of this element will cause the OCI symbol to appear at that point in the running text. This element should only be used in running text, e.g., to define the OCI symbol in a paragraph. The "oci" attribute should be used to place the OCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.6.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

ocp

Observable Critical Process

Description: Identifies the OCP symbol. Use of this element will cause the OCP symbol to appear at that point in the running text. This element should only be used in running text, e.g., to define the OCP symbol in a paragraph. The "ocp" attribute should be used to place the OCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.6.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

para

Paragraph

Description: Identifies text within a paragraph without regard to title, heading, etc. For example, a NOTE consists of a heading and one or more paragraphs.

Source paragraph: 4.2.9.5

Content Model: (((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+) | (randlist | deflist | seqlist))+

caution, cautdef, note, notedef, warning, warndef, %parazero, %nparcon, %nparcon1, %stepcon, wpgentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
xrefid	IDREF	#REQUIRED	Allows the user to set up an external reference.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type

inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

para0

Primary Paragraph

Description: Identifies a primary paragraph within the manual.

Source paragraph: 4.2.9.5.1.1

Content Model: ((title,warning*,caution*,note*,(para,note?))?,(step1* | ldstep1*))
%fpi, safesum, %append

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

param

Parameter

Description: Used with Object Media to provide textual information about the application being invoked.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

partno

Part Number

Description: Identifies the part number of the equipment on the title page.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1b

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

prtitle, pslist, lrpenry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

pgbrk

Page Break

Description: Identifies where a page will begin. Page breaks can be placed at the top of each logical page to identify where the page should start.

Source paragraph: 4.2.1.1

Content Model: EMPTY

docnmmunld

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pgnumber	CDATA	#IMPLIED	Allows the author to assign the pgnumber.
chglevel	NMTOKEN	#IMPLIED	Specifies what level of change the manual is on.
emergency	(0 1)	#IMPLIED	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
shrink	CDATA	#IMPLIED	Used to shrink vertical space so that overflowed text will pull back to the desired page.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
hyphflag	NUMBER	#IMPLIED	Toggle whether or not hyphen will be used for the last word on the last line.
paraflag	NUMBER	#IMPLIED	Toggle wheter or not last para will split.

phrase

Downgrade Phrase

Description: Identifies the text of the downgrade notice on the title page.

Source paragraph: 4.4

Content Model: #PCDATA

downgrd

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

postldinsp

Post Loading Inspection

Description: Subordinate paragraph under munitions loading procedures of Chapter 2. Contains information to ensure that safety devices are installed or removed as required.

Source paragraph: 3.3.3.3.6 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*))

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltypes	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

precaut

Precaution

Description: Identifies general safety precautions in the safety summary. The FOSI will automatically place a bullet to the left of each precaution.

Source paragraph: 4.5.10.1

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+) -(figure | table | foldout | warning | caution | precaut)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	(U C S N) N		Identifies security level of the document

preentry

Primary Index Entry

Description: Used by author to identify primary entries that will be included in the index.

Source paragraph: 4.2.9.8

Content Model: (topic)

index

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

pretmidno

Previous Technical Manual Identification Number (Not Used; Under Review)

Description: Identifies the previous technical manual identification number of the manual on the title page. This element is used only when the manual number has been changed. The FOSI will automatically generate the 'Formerly' prefix preceding the former manual number.

Source paragraph:

Content Model: #PCDATA

% i d i n f

preunload

Preunloading

Description: Subordinate paragraph under munitions loading procedures of Chapter 2. Contains information about preparing the aircraft/weapons for unloading.

Source paragraph: 3.3.3.4.2 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*))

munitunloadproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.

indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

prindex

Primary Index (Not Used; Under Review)

Description: The primary alphabetical index in the manual.

Source paragraph: 4.2.9.8

Content Model: #PCDATA

% t e x t

priorInch

Immediately Prior to Launch

Description: Subordinate paragraph in Loading Procedures of Chapter 2. Contains information for placing aircraft in a launch configuration.

Source paragraph: 3.3.3.3.8 (9977K)

Content Model: (%nparcon;, subparal*)

rackload

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type

inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: 4.5.1.3e

Content Model: ((nomen, (modelno | partno | typedes | pslist | nsn)+, serno*) | subject) %idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

pslist

Part/Serial Number List

Description: Identifies a listing on the title page that corresponds a particular part number with associated serial numbers. This element could also be used to correspond model numbers with serial numbers, etc.

Source paragraph: 4.5.1.3.4

Content Model: (partno, serno)+

prtitle

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

pubdate

Publication Date

Description: Identifies the basic date of the manual on the title page.

Source paragraph: 4.5.1.16

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

rackload

Loading Procedures

Description: Subordinate paragraph under munitions loading procedures of Chapter 2. Contains aircraft preparation, weapons (munitions) preparation, cartridge installation, postloading inspection, delayed flight or alert, immediately prior to launch.

Source paragraph: 3.3.3.3 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), airprepld, loadprep, ((cartins, load) | (load, cartins))+, postldinsp, dlayflt, priorlnch) | natitle) +(figure | table | foldout)

munitldproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

randlist

Random List

Description: Identifies a random list. All items within the random list will appear unnumbered, on separate lines, in the order they were entered by the author.

Source paragraph: NONE

Content Model: (title?, item+)

%list

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
prefix	CDATA	#IMPLIED	If prefix is used, the bullets will not appear that are generally formatted by the FOSI.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision
security	U C S N	N	Allows security classification of section.

ratd

Record of Applicable Technical Directives

Description: Identifies the record of applicable technical directives table.

Source paragraph: 4.5.9.4

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1* | ldstep1*), subpara1*, (typeno, date?, title, ecprno?, dateinc?, remarks?)*))

ratddesc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

ratddesc

Record of Applicable Technical Directives Description

Description: Identifies the record of applicable technical directives paragraph.

Source paragraph: 4.5.9.4

Content Model: ((%parazero;, subparal*), ratd?)

%fpi

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.

verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

ratdentry

Record of Applicable Technical Directives Entry

Description: Identifies the record of applicable technical directives entries.

Source paragraph: 4.5.9.4

Content Model: ((typeno, date?, title, ecprno?, dateinc?, remarks?)*)

ratd

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

rear

Rear Matter

Description: Identifies the rear matter of the manual.

Source paragraph: 4.2.9.6, 4.2.9.7, 4.2.9.8, & 4.6

Content Model: (appendix*, glossary?, index?, foldsect?)

docnnmunld

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numcols	(1 2)	#REQUIRED	Allows the author to define one column or two.

remarks

Remarks Entry

Description: Identifies an entry in the remarks column of the record of applicable technical directives.

Source paragraph: 4.5.9.4e

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

ratdentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

removepg

Remove Page Column Entry

Description: Identifies an entry within the Remove Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

revnum

Revision Number

Description: Identifies the revision number of the manual on the title page.

Source paragraph: 4.8

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

row

Row

Description: Identifies a row in a table.

Source paragraph: 4.2.7

Content Model: (entry | entrytbl)+

tbody, thead

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rowsep	NUMBER	#IMPLIED	Allows the author to specify row separator width.
valign	(TOP BOTTOM MIDDLE)	#IMPLIED	Allow the author to vertically align text within table rows.
security	U C S N	N	Allows security classification of section.

safesum

Safety Summary

Description: Identifies the safety summary of the manual. The title is automatically generated by the FOSI.

Source paragraph: 4.5.10

Content Model: (para0+)

%frnt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

safing

Safing

Description: Subordinate paragraph under munitions loading procedures of Chapter 2. Contains information required to safe aircraft/weapons.

Source paragraph: 3.3.3.4.1 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*)

munitunldproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

scope

Scope

Description: Servicing and Loading chapter description paragraph.

Source paragraph: 3.7.2.2.1 (9977K)

Content Model: %text1

general

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.

deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

seal

Seal

Description: Department of the Navy Seal, with command identifier.

Source paragraph: 4.5.1.5

Content Model: EMPTY

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

secentry

Secondary Index Entry

Description: Used by author to tag data for inclusion in the index as a secondary topic.

Source paragraph: 4.2.9.8

Content Model: (topic)

index

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

secindex

Section Index (Not Used; Under Review)

Description: Identifies a section Index of the manual.

Source paragraph: 4.2.9.4

Content Model: #PCDATA

% t e x t

section

Section

Description: Identifies a section of the manual, the next further breakdown of a chapter.

Source paragraph: 4.2.9.4

Content Model: (%titles;, para0+)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

sensorrem

Sensor Removal

Description: Provides necessary steps to safe and remove sensors from nunnuclear munitions.

Source paragraph: 3.6.3.4.4 (9977K)

Content Model: (%nparcon;, subpara1*)

munitunloadproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

seqlist

Sequential List

Description: Identifies a sequential list. All items within the sequential list will appear numbered, on separate lines, in the order they were entered by the author.

Source paragraph: MIL-PRF-28001

Content Model: (title?, item+)

%list

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numstyle	(ALPHAUC ALPHALC ARABIC ROMANUC ROMANLC)	#IMPLIED	Allows the author to specify number style.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

seqno

Hazardous Material Warning Icon Sequence Number

Description: Identifies the sequence number of the hazardous material warning icons in the safety summary.

Source paragraph: (MIL-STD 38784A DRAFT)

Content Model: #PCDATA

%icon

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

serno

Serial Number

Description: Identifies serial numbers of the equipment on the title page.

Source paragraph: 4.5.1.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

prtitle, pslist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

spanspec

Span Specification

Description: Used to join two or more columns in a table. Span specifications are similar to column specifications (<colspec>) except that they describe areas of the table that can be spanned (joined) using a table entry (<entry>). For example, a three-column table may have columns named "1", "2", and "3" respectively. A span named "23" may be declared using "spanspec". When "spanname='23'" is used on an "entry", that entry would occupy the space in both columns 2 and 3.

Source paragraph: MIL-PRF-28001 8.4.5.3

Content Model: EMPTY

tgroup, entrytbl

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
namest	NMTOKEN	#REQUIRED	Allows author to identify the column name to start the span.
nameend	NMTOKEN	#REQUIRED	Allows author to identify the column name to end the span.
spanname	NMTOKEN	#IMPLIED	Allows the author to identify the name of the span.

align	(LEFT RIGHT CENTER JUSTIFY CHAR)	CENTER	Allows you to align entered text.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Alignment Character
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows.

specsafreq

Specific Safety Requirements

Description: Subordinate paragraph in the General primary paragraph of Chapter 2. Contains all specific safety procedures pertaining to the weapon (munition) and loading procedures.

Source paragraph: 3.3.3.2.3 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*)

general

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

step1

First Level Procedural Step

Description: Identifies a first level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, note?(step2, step2+)?)

%parazero, %nparcon, %nparcon1

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

step2

Second Level Procedural Step

Description: Identifies a second level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, note?, (step3, step3+)?)

step1

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	(0 1)	#IMPLIED	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcg	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocg	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
revchg	NUMBER	0	Used to generate a revision.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.

step3

Third Level Procedural Step

Description: Identifies a third level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (warning*, caution?, note?, para, note?, (step4, step4+)?)

step2

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
revchg	NUMBER	0	Used to generate a revision.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.

step4

Fourth Level Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (warning*, caution?, note?, para, note?)

step3

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcg	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hcg	NUMBER	0	Hardness Critical Item
ocg	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

strayvoltchk

Stray Voltage Checks

Description: Section VII of Chapter 1. Contains all necessary steps to perform a stray voltage test of weapons (munitions) control/release/fire and jettison systems.

Source paragraph: 3.3.2.9 (9977K)

Content Model: (para0+ | natitle)

suppinfo

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subfig

Subfigure

Description: Identifies a subfigure. This element is used for multisheet illustrations, each sheet being a subfigure. The FOSI will automatically generate the sheet count (e.g., 'Sheet 1 of 10', 'Sheet 2', etc.)

Source paragraph: 4.2.4.2

Content Model: ((graphic, legend?) | figtable)

%fig

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
orient	(PORT LAND1)	PORT	Allows you to specify the orientation of the graphic and/or table. Options are portrait and landscape.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

subject

Subject

Description: Identifies the prime title of the manual on the title page.

Source paragraph: 4.5.1.3.4

Content Model: #PCDATA

prtitle

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

subjinfo

Subject Information (Not Used; Under Review)

Description: Identifies subject information that appears at the top of every column in a chapter. This first "subjinfo" tag in a chapter should be placed after the chapter tag or the first section tag (if used). Additional "subjinfo" tags have no restrictions on placement and should be used wherever the information changes.

Source paragraph:

Content Model: EMPTY

subobjmed

Description:

Source paragraph:

Content Model: (object)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	
label	CDATA	#IMPLIED	
delttype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(U C S N)	N	Identifies security level of the document

subpara1

First Subordinate Paragraph

Description: Identifies a first subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title, para, note?, (step1* | ldstep1*), subpara2*))

%text1, %symsect, %lrp, abbrsect, applicdef, para0, ratddesc, tctolist, tmimprep

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.

verstatus	(UNVERIFIED VERIFIED)		Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara2

Second Subordinate Paragraph

Description: Identifies a second subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), subpara3*))

subpara1

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara3

Third Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), sub-para4*))
subpara2

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara4

Fourth Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), subpara5*))

subpara3

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara5

Fifth Subordinate Paragraph

Description: Identifies a fifth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), subpara6*))

subpara4

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.

deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara6

Six Subordinate Paragraph

Description: Identifies a sixth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), subpara7*))

subpara5

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".

hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara7

Seventh Subordinate Paragraph

Description: Identifies a seventh subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*), subpara8*))

subpara6

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.

esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcf	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hcf	NUMBER	0	Hardness Critical Item
ocf	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subpara8

Eighth Subordinate Paragraph

Description: Identifies a eighth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: ((warning*, caution?, note?, title?, para, note?, (step1* | ldstep1*))

subpara7

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.

emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

subtitle

Subtitle

Description: Identifies the subtitle of the manual on the title page.

Source paragraph: 4.5.1.3.5

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

supersed

Supersedure Notice

Description: Identifies the supersede notice on the title page.

Source paragraph: 4.5.1.6

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

suppequipdesc

Support Equipment

Description: Subordinate paragraph in the General section of Chapter 2. Contains a list of all special equipment that may be needed to complete the requirements of this chapter.

Source paragraph: 3.3.3.2.2 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*)

general

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

suppinfo

Supplemental Information

Description: Identifies Chapter 1 of the manual, containing Sections I through VIII. Includes all procedures related to weapons (munitions) on the aircraft, with the exception of weapons (munitions) loading/unloading.

Source paragraph: 3.6b (9977K)

Content Model: (%titles;, gensafreq, emergproc, airdesc, genproc, airprep, fctfuncchk, strayvoltchk, section*) +(figure | table | foldout)

body

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	Allows the author to identify each element and later reference it by the id value.
security	U C S N	N	Allows security classification of section.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

suppl

Supplement Notice

Description: Identifies the supplement notice on the title page.

Source paragraph: 4.5.1.8

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

symsect

Symbol Paragraph

Description: Identifies the paragraph used to define symbols (e.g., ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: (((title, warning*, caution?, note?, (para, note?)?), (step1* | ldstep1*), subpara1*, (symtitle?, (term, def)+))

%fpi

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.75IN	Allows you to set the right term width.
ltermwidth	NUTOKEN	0.75IN	Allows you to set the left term width.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED "UNVERIFIED" VERIFIED)		Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcf	NUMBER	0	Fracture Critical Process
hcf	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hcf	NUMBER	0	Hardness Critical Item
ocf	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item

applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

symtitle

Symbol Paragraph

Description: Identifies the title used to define symbols (e.g., ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

%symsect

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

table

Table

Description: Identifies a table.

Source paragraph: 4.2.7

Content Model: (title, tgroup)

suppinfo, munitldproc, %inclus, foreword, safesum

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	Description not available.

frame	(TOP BOT- TOM TOPBOT ALL SIDES NONE)	ALL	Allows you to choose what type of table frame you need.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to seperate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to seperate rows.
orient	(PORT LAND1)	PORT	Allows you to specify the orientation of the graphic and/or table. Options are portrait and landscape.
pgwide	NUMBER	1	Specifies if the table fills the page or column. Set it equal to "0", it will fit in column.
cellcont	(CONTINUED CONT)	CONTINUED	Description not available.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
footnotes	(PAGE END)	#IMPLIED	Description not available.
leftind	CDATA	#IMPLIED	Allows author to specify left indent if desired.
rightind	CDATA	#IMPLIED	Allows author to specify right indent if desired.
leftmar	NUTOKEN	#IMPLIED	Allows you to define a left margin if desired.
rightmar	NUTOKEN	#IMPLIED	Allows you to define a right margin if desired.
topmar	NUTOKEN	#IMPLIED	Allows author to specify top margin if desired.
botmar	NUTOKEN	#IMPLIED	Allows author to specify bottom margin if desired.
mindepth	NUTOKEN	#IMPLIED	Minimum cell depth.
pgdeep	NUMBER	0	Specifies that the table will fit page depth.
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
revchg	NUMBER	0	Used to generate a revision.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
security	U C S N	N	Allows security classification of section.

tabmat

Table Material

Description: For table material that does not require a title.

Source paragraph: 4.3.9

Content Model: (tgroup+)

%text, chglist, legend, verstat

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	Description not available.
frame	(TOP BOT- TOM TOPBOT ALL SIDES NONE)	ALL	Allows you to choose what type of table frame you need.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to seperate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to seperate rows.
orient	(PORT LAND1)	PORT	Allows you to specify the orientation of the graphic and/or table. Options are portrait and landscape.
pgwide	NUMBER	1	Specifies if the table fills the page or column. Set it equal to "0", it will fit in column.
cellcont	(CONTINUED CONT)	CONTINUED	Description not available.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
footnotes	(PAGE END)	#IMPLIED	Description not available.
leftind	CDATA	#IMPLIED	Allows author to specify left indent if desired.
rightind	CDATA	#IMPLIED	Allows author to specify right indent if desired.
leftmar	NUTOKEN	#IMPLIED	Allows you to define a left margin if desired.
rightmar	NUTOKEN	#IMPLIED	Allows you to define a right margin if desired.
topmar	NUTOKEN	#IMPLIED	Allows author to specify top margin if desired.
botmar	NUTOKEN	#IMPLIED	Allows author to specify bottom margin if desired.
mindepth	NUTOKEN	#IMPLIED	Minimum cell depth.
pgdeep	NUMBER	0	Specifies that the table will fit page depth.
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
revchg	NUMBER	0	Used to generate a revision.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
security	U C S N	N	Allows security classification of section.

tbody

Table Body

Description: Identifies the body of a table (e.g., material below the boxheads).

Source paragraph: 4.3.9

Content Model: (row+)

entrytbl, tgroup

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
valign	(TOP MID-DLE BOT-TOM)	TOP	Description not available.

tctolist

Time Compliance Technical Orders Paragraph

Description: Identifies the time compliance technical orders paragraph and the associated table.

Source paragraph: 4.5.9.3

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1* | ldstep1*), subpara1*, tctotbl?)

%fpi

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
-----------	------	---------	-------------

label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcg	NUMBER	0	Fracture Critical Process
hcg	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hcg	NUMBER	0	Hardness Critical Item
ocg	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

tctono

Time Compliance Technical Order Number

Description: Identifies an entry in the TCTO Number column in the TCTO table.

Source paragraph: 4.5.9.3

Content Model: #PCDATA

tctorow

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

tctorow

Time Compliance Technical Orders Row

Description: Identifies a row in the time compliance technical orders table.

Source paragraph: 4.5.9.3

Content Model: (tctono, title, date)

tctotbl

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

tctotbl

Time Compliance Technical Order Table

Description: Identifies the table that lists all TCTOs applicable to the manual. The FOSI will automatically generate the table title and the column headings (boxheads).

Source paragraph: 4.5.9.3

Content Model: (tctorow+)

tctolist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.
security	U C S N	N	Allows security classification of section.

term

Term

Description: Identifies an entry in the term portion of a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: 4.3.4

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

%symsect, acronym, acronymlist, applic, applichd, defhd, deflist

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

tfndisplay

Table Footnote Display

Description: This element is for displaying footnotes in a 38784 table model. Footnotes to tables will be displayed at the end of the table. This element should be placed in a span in the last row of the table.

Source paragraph: 4.2.7.5

Content Model: EMPTY

figtable, table

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

tfnid

Table Footnote Id

Description: This element is for placing a footnote in a 38784 table model. A superscript will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: #PCDATA

tfoot

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows author to identify each element and later reference it by its id value.
tfntype	(NUM AL-PHA SYM)	NUM	Allows author to decide how the table footnote will be marked.
tfnsymbol	CDATA	#IMPLIED	Allows author to choose a symbol to use to mark table footnote.
tfnval	CDATA	#IMPLIED	Allows author to assign a value to the table footnote.

tfnref

Table Footnote Reference

Description: This element is for referencing a footnote in a 38784 table model that was created with a table footnote id. The superscript that was generated from the table footnote id will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: EMPTY

figtable, table

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Allows the user to set up an external reference.

tfoot

Table Foot

Description: The foot of the table.

Source paragraph: 4.2.7.5

Content Model: (tfnid*)

figtable, table

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

tgroup

Table Group

Description: Identifies a table group, which consists of a table heading (boxheads) and a table body.

Source paragraph: 4.2.7

Content Model: (colspec*, spanspec*, thead?, tbody)

%tabl, figtable, tabmat

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Allows author to specify number of columns in table.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to seperate columns.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to seperate rows.

align	(LEFT RIGHT CENTER JUSTIFY CHAR)	#IMPLIED	Allows you to align entered text.
leftind	CDATA	#IMPLIED	Allows author to specify left indent if desired.
rightind	CDATA	#IMPLIED	Allows author to specify right indent if desired.
leftmar	NUTOKEN	#IMPLIED	Allows you to define a left margin if desired.
rightmar	NUTOKEN	#IMPLIED	Allows you to define a right margin if desired.
topmar	NUTOKEN	#IMPLIED	Allows you to define a top margin if desired.
botmar	NUTOKEN	#IMPLIED	Allows you to define a bottom margin if desired.
mindepth	NUTOKEN	#IMPLIED	Allows you to define a minimum depth if desired.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Alignment Character

thead

Table Heading (Boxheads)

Description: Identifies a table heading (boxheads). The table heading (boxheads) repeat when the table breaks across a column or page.

Source paragraph: 4.2.7.3

Content Model: (colspec*, row+)

entrytbl, tgroup

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
valign	(TOP MIDDLE BOTTOM)	BOTTOM	Description not available.

title

Title

Description: Identifies a title (e.g., chapter, paragraph, table, etc.). The title should be tagged exactly as it is to appear in the table of contents. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: MIL-STD-38784

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex)+

%titles, %fig, deflist, lrpentry, randlist, ratdentry, seqlist, tctorow, wpgentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

tmidno

Technical Manual Identification Number

Description: Identifies the technical manual identification number. When used on the title page (<idinfo>), it will cause the technical manual number to appear on the title page and at the top of each page in the manual. When used in the list of related publications (<lrp>), will cause the technical manual number to be placed in the "Publication Number" column.

Source paragraph: 4.2.1.5 & 4.5.9.2

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

%idinf, lrpentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD)	#IMPLIED	Author must identify what service is used.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
revchg	NUMBER	0	Used to generate a revision.
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
security	U C S N	N	Allows security classification of section.

tmimprep

Technical Manual Improvement Report

Description: Identifies the technical manual improvement report paragraph.

Source paragraph: 4.5.9

Content Model: ((title,warning*,caution?,note?,(para,note?)?,(step1* | 1dstep1*),subpara1*)

%fpi

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The FOSI will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(UNVERIFIED VERIFIED)	"UNVERIFIED"	Identifies verification status.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
emergency	NUMBER	0	Emergency Border. If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
deltype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

topic

Index topic

Description: Used by author to tag topics that will be appear in the index. Used as subelement for preentry and secentry.

Source paragraph: 4.2.9.8

Content Model: #PCDATA

preentry, secentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
page	CDATA	#REQUIRED	Description not available.

typedes

Type Designation

Description: Identifies a type designation on the title page.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1B

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

lrpreentry, prttitle

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

typeno

Directive Type and Number

Description: Identifies an entry in the "Type/No" column of the record of applicable technical directives table.

Source paragraph: 4.5.9.4a

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex) +

ratdentry

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	U C S N	N	Allows security classification of section.

unload

Unloading

Description: Section III of Chapter 2. Contains information for unloading weapons (munitions) from aircraft.

Source paragraph: 3.3.3.4.2 (9977K)

Content Model: ((%titles;)?, warning*, caution*, note*, (para, note*)?, (step1* | ld-step1*), subpara1*)

munitunloadproc

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pghead	CDATA	#IMPLIED	Procedural pages shall carry identification consisting of particular sidehead depending on what is on the page and whether it is recto or verso.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Description not available.
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision

verbatim

Verbatim Text

Description: Identifies a block of text where text layout will remain as it appears in the tagged instance. All spaces/carriage returns will be preserved, and no spaces or carriage returns will be added by the system. The FOSI will use a monospace font to format verbatim text. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: MIL-PRF-28001

Content Model: CDATA

%text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
allowbrk	NUMBER	1	Description not available.
security	U C S N	N	Allows security classification of section.

verstat

Verification Status Page

Description: Identifies the verification status page in the manual. This information is automatically compiled by the FOSI. This element should not be used if a verification status page is not desired.

Source paragraph: 4.5.4

Content Model: (tabmat?)

%frnt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volcontents

Volume Contents

Description: Identifies a volume contents.

Source paragraph:

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	This attribute should be set equal to 1. when the acronymlist is autogenerated.

vollep

Volume List of Effective Pages

Description: Identifies the volume List of Effective Pages.

Source paragraph: 4.2.9.1

Content Model: (vollepcontents)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

vollepchg

Volume LEP Change Number

Description: Volume Change Number for each entry in the VOLLEP.

Source paragraph: 4.5.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volleppcontents

Volume Contents

Description: Identifies the volume.

Source paragraph: 4.2.9.1

Content Model: (volleppentry+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	This attribute should be set equal to 1. when the acronymlist is autogenerated.
lepcount	CDATA	#IMPLIED	Defines the number of pages in the lep for each volume.

volleppentry

Volume LEP Entry

Description: LEP entry that should appear in the volume LEP.

Source paragraph: 4.5.3

Content Model: volleppage, vollepchg

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volleppage

Volume LEP Page Number

Description: Volume Page Number for each entry in the VOLLEP.

Source paragraph: 4.5.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volnot

Volume Notice

Description: Identifies the volume notice on the title page.

Source paragraph: 4.2.9.1

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volnum

Volume Number

Description: Identifies the volume number on the title page.

Source paragraph: 4.2.9.1

Content Model: #PCDATA

%idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
NONE			

volume

Volume

Description: Identifies a volume.

Source paragraph: 4.2.9.1

Content Model: ((front | auxfront), body, rear?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	DELETE REAL RESERVE NA	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	EMPTY DELETED RESERVED NOTAPP	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(U C S N) N		Identifies security level of the document
docid	CDATA	#IMPLIED	Allows for the author to define an identification number for the document.
docstat	(REVISION CHANGE PRELIM DRAFT FORMAL)	PRELIM	Author can stipulate what form the manual is in.
verstatpg	(VER UN- VER)	VER	Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail.
Index	NUMBER	0	Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC

service	(AF NAVAIR #REQUIRED NAVSEA SPAWARS ARMY MC DLA CG DOD)		Defines the branch of service.
volpages	NUMBER	0	Indicates whether the page numbers within the volume use the volume number prefix. Zero indicates standard page numbers. 1. indicates a volume prefix will be used.
resetnbrs	NUMBER	1	Allows you to reset chapter numbers when continuing to a second or subsequent volume. 1. will reset chapter numbers back to 1. Zero will continue with the chapter numbers.

warning

Warning

Description: Identifies a WARNING in the manual. Multiple warning tags may be used only when it is desired to change the warning icon (standard or hazardous warning graphic).

Source paragraph: 4.3.10

Content Model: (icon?, para*)

%parazero, %nparcon, %wcn, %entry, safesum

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
delttype	"DELETE REAL RESERVE NA"	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	"EMPTY DELETED RESERVED NOTAPP"	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision.

xref

Cross-reference

Description: Identifies a cross-reference to a paragraph, figure, table, etc.

Source paragraph: 4.6.16.2

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
HyTime	NAME #FIXED	CLINK	Used in combination with HyTime to establish contextual link.
HyNames	CDATA #FIXED	LINKEND XREFID	Used in combination with HyTime to establish contextual link.